

# MNERAD-SLAVE-REVB-6/11/14

## Radian SLAVE E-Panel

### NOTES:

1-FIRST 2 BREAKERS ON LEFT ARE MNEACQZD502P

2-RIGHT TWO BREAKERS ARE MNEDC175s

3-ALL WIRING IS #6 THHN (EXCEPT WHERE MARKED)

4-INSTALL THE 3 DC BUS BARS THAT GO TO THE INVERTER

5-INCLUDE MOUNTING FEET, 1INCH NIPPLE KIT AND HARDWARE

6-VERIFY CONTINUITY OF ALL BREAKERS

7-USE NO SLIDER PLATE

